

ADDITION TO THE PPE EXAMINATION PROCEDURE FOR

ABSORBICA lanyards L57, L70150 I, L70150 Y, L70150 IM, L70150 YM

MAY 2011



1 - Open the zipped protective pouch which contains the tear webbing part of the absorber.



2 - Carefully remove the white tear webbing part from the pouch.



3 - At the lanyard end, check on each side of the webbing that there are 4 black bar tacks connecting the tear webbing to the attachment loop or steel ring.



4 - At the harness end, check on each side of the webbing that there are **4** black bar tacks connecting the tear webbing to the attachment loop.



If any of the bar tacks do not meet the above requirements (complete or partial absence of one or more bar tacks, distorted, damaged or cut threads) then the item must be removed from service and forwarded to your Petzl distributor.

5 - Continue with the complete PPE examination procedure for the item.

(instructions can be found on http://www.petzl.com/en/ppe-checking).

Record the results of each PPE Examination.

In case of any doubt, contact your Petzl distributor.

Forward all information to your local PETZL distributor :
Client – country – number of items examined

For each examination performed record; the client name and contact details, date of examination, Petzl product reference, individual serial number, results of the inspection and the name of the inspector who performed the examination.



ADDITION TO THE PPE EXAMINATION PROCEDURE FOR

ABSORBICA lanyards L58, L58 MGO, L59, L59 MGO

MAY 2011



1 - Open the zipped protective pouch which contains the tear webbing part of the absorber.

2 - Carefully remove the white tear webbing part from the pouch.



3 - At the lanyard end, check on each side of the webbing that there are **5** white bar tacks connecting the tear webbing to the black lanyard components.



4 - At the harness end, check on each side of the webbing that there are **4** black bar tacks connecting the tear webbing to the black attachment loop.



5 - Continue with the complete PPE examination procedure for the item.

(instructions can be found on http://www.petzl.com/en/ppe-checking).

Record the results of each PPE Examination.

In case of any doubt, contact your Petzl distributor.

Forward all information to your local PETZL distributor :
Client – country – number of items examined

For each examination performed record; the client name and contact details, date of examination, Petzl product reference, individual serial number, results of the inspection and the name of the inspector who performed the examination.